
Sektion 2. Utlandstillverkad flygmateriel

TITEL: Funktionskontroll av elektriska bränslekranen

GÄLLER: SE 3130 och 313 B ALOUETTE II, SA 3180, SA 318 B och
SA 318 C ALOUETTE ASTAZOU.

ÅTGÄRD: Utför åtgärder angivna i section II i Flight Manual.

**TID FÖR
ÅTGÄRD:** Varje gång vid start av motor och rotor.

UNDERLAG: Aircraft Flight Manualer:
SE 3130 - Normal revision nr 28 daterad oktober 95
SA 3180, SA 318 B och SA 318 C - Normal revision nr 25 daterad
oktober 1995.

REFERENS: DGAC AD 96-072-053(B) (kopia bifogad)

**BESLUTS
DATUM:** 1996-04-19

LFS: 1996:29

Åtgärd enligt LVD utgör nödvändig förutsättning för ifrågavarende flygmateriels luftvärdighet. Referens BCL M 1.11. Anteckning om åtgärd, som vidtagits i enlighet med LVD, skall införas i teknisk journal för berörd flygmateriel med hänvisning till ifrågavarande LVD-nummer. Angivet underlag refererar till senaste gällande revision/utgåva. LVD utges i luftfartsverkets författningssamlingar LFS.

G S A C

AIRWORTHINESS DIRECTIVE

released by DIRECTION GENERALE DE L'AVIATION CIVILE

Inspection and/or modifications described below are mandatory. No person may operate a product to which this Airworthiness Directive applies except in accordance with the requirements of this Airworthiness Directive

Translation of 'Consigne de Navigabilité'
ref.: 96-072-053 (B)
In case of any difficulty, reference should
be made to the French original issue.

EUROCOPTER FRANCE**313 - 318 Helicopters****Electric fuel cock**

This Airworthiness Directive applies to SE 3130 and 313 B ALOUETTE II and SA 3180, SA 318 B and SA 318 C ALOUETTE ASTAZOU helicopters.

Further to an engine flame-out, due to the closure of the electric fuel cock, which resulted in an accident, the following measures are rendered mandatory from the effective date of this Airworthiness Directive :

Each time the engine and the rotor are started, carry out the new specific checks described in Section II of the Flight Manual, i.e. :

- Slowly move the throttle lever forward until it reaches its end-of-travel stop.
- Set the starting switch to "OFF".

The engine should not go out.

- Set the switch back to "ON" and continue the normal Flight Manual procedure.

Ref. : Aircraft Flight Manuals -

- SE 3130 ; Normal revision n° 28 dated October 1995
- SA 3180, SA 318B and SA 318C : Normal revision n° 25 dated Oct.95

EFFECTIVE DATE : APRIL 06, 1996

v/DJ

March 27, 1996

EUROCOPTER FRANCE
313 - 318 Helicopters

96-072-053 (B)